

iPhone Kitting Instructions

Step-by-step labeling, setup, quality check and packing — for CDW Configuration Services

VERSION

1.2

LAST UPDATED

September 11, 2026

OWNER

BCH CMDI (Clinical Mobile Devices)

MANAGEMENT

Apple Business Manager + Omnisia

Workspace ONE

How this works

Every iPhone on this order is already registered to Boston Children's Hospital in **Apple Business Manager (ABM)**. The first time a phone is powered on and connected to Wi-Fi, it automatically downloads BCH's management profile and then installs BCH's apps and settings on its own. Most setup screens are skipped automatically.

Your job: label each phone, walk it through the few remaining setup screens, open a handful of apps and accept their prompts, set a few settings, check it, and pack it.

0 Prepare

Supplies, Wi-Fi, charge

1 Label

Serial number on the phone's back

2 Setup

Power on, enroll in BCH management

3 Hub app

Open, accept prompts

4 Apps installed

Wait until every app finishes

5 Settings

Locker, 5G, App Store

6 Rover & Haiku

Open once, accept prompts

7 Quality check

Verify and log each phone

8 Case & pack

Case on, box, ship

Menu names can differ slightly between iOS versions.

The rules that matter most

Breaking one of these usually means the phone has to be erased and set up again.

- 1 Never skip Remote Management.** If the *Remote Management* screen does not appear during setup, stop working on that phone and follow Troubleshooting.
- 2 Never sign in with an Apple Account (Apple ID)** — not in setup, the App Store, or Settings.
- 3 Never sign in to any app** with a username or password. Just open the apps listed here and accept their prompts.
- 4 Keep phones on Wi-Fi and on power** until every app has finished installing.
- 5 Do not install, delete or move apps, and do not change settings** that aren't in this guide. BCH's management handles everything else.
- 6 When something doesn't match this guide, set the phone aside and ask BCH** — don't improvise.

0 Before you start

Supplies

- The iPhones, cases and charging cables on this order
- Label printer and labels for the serial number
- Isopropyl alcohol wipes (to clean the phone back before labeling)
- Shipping boxes and padding
- The device manifest spreadsheet (see Manifest)

Wi-Fi

- **Any Wi-Fi network with internet access** works. Once enrolled, BCH's management takes over the phone's Wi-Fi settings.
- Avoid networks with a **sign-in / splash page** (guest Wi-Fi at hotels, etc.) — enrollment can fail behind one.

Get ready

1. ☐ Charge phones to at least **50%** before starting, and keep them on power during setup.
2. ☐ Open the manifest and fill in one row per phone as you go.

1 Label the phone

The serial number label goes on the **back of the iPhone itself — not on the case.**

1. ☐ Print a label with the iPhone's **serial number**. The serial number is printed on the iPhone's retail box — keep the box until the label is on.

2. ☐ Wipe the back of the phone with an alcohol wipe and let it dry.

3. ☐ Apply the label to the back of the phone.
 - Do **not** cover the cameras, flash, or microphone.
 - Keep it flat and straight, with no bubbles or lifted corners. Press firmly for a few seconds.

4. ☐ After setup, the serial in **Settings** > **General** > **About** must match the label — this is checked in Quality check.

2 Power on & setup

Press and hold the side button until the Apple logo appears. BCH's configuration skips most setup screens automatically, so you should only see the ones below.

SCREEN	WHAT TO DO
Hello	Swipe up from the bottom of the screen.
Language	Select English .
Country or Region	Select United States .
Choose a Wi-Fi Network	Select any Wi-Fi network with internet access and enter its password.
Remote Management	Required. The screen says the iPhone will be configured by Boston Children's Hospital . Tap Enroll This iPhone (may say Continue) and wait for it to finish. If this screen never appears, stop — see Troubleshooting.
Location Services	Tap Enable Location Services .
Any other screen	Accept the default and tap Continue — unless it asks you to sign in or create a passcode. For those, choose <i>Set Up Later / Not Now</i> , and let BCH know which screen appeared.

✓ **Expected:** The Home Screen appears and BCH's apps start installing on their own (gray icons that say *Waiting...* or *Loading...*).

3 Hub app (Omnissa Intelligent Hub)

Wait until the **Hub** icon finishes installing (no gray icon or progress ring), then:

1. ☐ Tap **Hub** to open it.
2. ☐ **Data & Privacy:** tap **Accept**.
3. ☐ **Location:** iOS first offers only *Allow Once / Allow While Using App / Don't Allow*. Tap **Allow While Using App**. When a second prompt offers **Change to Always Allow**, tap it.
4. ☐ For **every other pop-up** (Notifications, Bluetooth, etc.) tap **Allow** / **Yes** / **Always Allow**.
5. ☐ Go through the remaining in-app screens and tap **I Understand** on each.
6. ☐ Double-check location: **Settings** > **Apps** > **Hub** > **Location** must be **Always**, and **Precise Location** must be **on**. Fix it here if the in-app prompt was missed.
✓ **Expected:** Hub location = Always, Precise Location on.

4 Confirm all apps are installed

Keep the phone on Wi-Fi and power. Apps install on their own — you do not need the App Store.

1. ☐ Wait until no icon on the Home Screen is gray, shows a progress ring, or says *Waiting... / Loading...*
✓ **Expected:** Every app icon is in full color and opens.

5 Device settings

SHORTCUT: THE CMDI GCT APP

If the **CMDI GCT** app is on the phone, open it — it walks you through these settings screen by screen. Then use the list below to confirm nothing was missed.

5.1 Locker

1. ☐ Open **Locker** and tap **Allow** / **Accept** on every prompt. Do not sign in.

2. ☐ Go to **Settings** > **General** > **AutoFill & Passwords** and turn **Locker** on.
✓ **Expected:** Locker is toggled on.

3. ☐ Go to **Settings** > **Apps** > **Locker** > **Live Activities** and turn **Live Activities** on.
✓ **Expected:** Live Activities toggle is green.

5.2 Cellular — 5G data mode

1. ☐ Go to **Settings** > **Cellular** > **Cellular Data Options** > **Data Mode** .

2. ☐ Select **Allow More Data on 5G**.
✓ **Expected:** Checkmark next to "Allow More Data on 5G".
If this option isn't shown, note it in the manifest and continue.

5.3 App Store — automatic downloads

1. ☐ Go to **Settings** > **Apps** > **App Store** .

2. ☐ Under *Automatic Downloads*: turn **App Downloads** on and **App Updates** on.

3. ☐ Under *Cellular Data*: turn **Automatic Downloads** on, then tap **App Downloads** and choose **Always Allow**.
✓ **Expected:** Automatic Downloads on; Cellular → App Downloads = Always Allow.

6 Rover & Haiku — first launch

Each app only needs to be opened once so its prompts are answered. **Do not sign in.**

Rover

1. ☐ Open **Rover**.
2. ☐ Tap **Accept** / **Allow** on every prompt.
3. ☐ Stop at the sign-in screen. Swipe up to close the app.

Haiku

1. ☐ Open **Haiku**.
2. ☐ Tap **Accept** / **Allow** on every prompt.
3. ☐ Stop at the sign-in screen. Swipe up to close the app.

7

Quality check — every phone

Do this for each phone before it goes in a case, and record the result in the manifest. A phone that fails any check does not ship — set it aside and report it.

CHECK	WHERE	PASS WHEN
Label matches phone	Settings > General > About	Serial Number on screen = serial on the label
Managed by BCH	Settings > General > VPN & Device Management	A Boston Children's Hospital management profile is listed
All apps installed	Home Screen	No app is gray or waiting
Hub location	Settings > Apps > Hub > Location	Always, Precise Location on
Locker AutoFill	Settings > General > AutoFill & Passwords	Locker on
Locker Live Activities	Settings > Apps > Locker	Live Activities on
5G data mode	Settings > Cellular > Cellular Data Options	Allow More Data on 5G
App Store downloads	Settings > Apps > App Store	Automatic Downloads on; Cellular App Downloads = Always Allow
Hub, Locker, Rover, Haiku	Open each app	Opens with no permission pop-ups left to answer
Physical condition	Look at the phone	No scratches, cracks or dead pixels; buttons and cameras work

8

Case, pack & ship

Case

1. ☐ Put the phone in its case. Make sure the label is flat and not wrinkled under the case.
2. ☐ **Power the phone off** (hold the side button and either volume button, then slide to power off). Phones ship powered off.

Pack

1. ☐ Take the **USB-C charging cable** out of each retail box and keep it. Then **discard the retail packaging** (boxes, inserts, paperwork) — phones do not ship in their Apple boxes.
2. ☐ Pack phones into **as few boxes as possible**, padded so they can't shift or rub screen-to-screen.
3. ☐ Pack **all charging cables in a separate box**. Label it **CHARGING CABLES — QTY ____**.
4. ☐ Number every box (**Box 1 of N**) and write the phone count on the outside.
5. ☐ Put a **packing list** inside each box listing the serial numbers in that box. Enter the box number for each phone in the manifest.
6. ☐ Email the completed manifest to your BCH contact **before** the shipment leaves, then send the tracking number(s).

A Device manifest

One row per phone, as an Excel or CSV file. BCH uses this to confirm every phone was set up and to find it by box.

COLUMN	WHERE TO FIND IT / NOTES
Serial Number	Settings › General › About
IMEI	Settings › General › About
Enrolled in BCH management (Y/N)	From Quality check
All QA checks passed (Y/N)	If N, explain in Notes
Box Number	e.g. 3 of 12
Technician initials & date	
Notes	Damage, missing 5G option, anything unusual

B Troubleshooting & when to stop

STOP AND SET THE PHONE ASIDE WHEN...

- The Remote Management screen never appeared, or someone signed in with an Apple Account.
- The phone is damaged or won't power on.
- The same problem repeats after following the fix below once.

Record the serial number and the problem in the manifest Notes column and report it to your BCH contact. Do not ship it — continue with the other phones while you wait for an answer.

PROBLEM	WHAT TO DO
No Remote Management screen — setup went straight to the Home Screen	The phone did not reach BCH's management. Erase it: Settings > General > Transfer or Reset iPhone > Erase All Content and Settings , then set it up again on a different Wi-Fi network. If it happens again, stop and report the serial.
"Unable to connect to the configuration server" or enrollment error	Check the Wi-Fi has internet and no sign-in page. Tap Try Again. If it fails twice, power off and report.
Apps stuck on Waiting... / Loading...	Confirm Wi-Fi is connected. Restart the phone and wait 15 more minutes. Still stuck: report the serial and app names. Don't install apps from the App Store.
Hub location isn't "Always"	Settings > Apps > Hub > Location → Always; turn on Precise Location.
Accidentally tapped "Don't Allow" in an app	Open Settings > Apps > (app name) and turn the permission back on.
A sign-in or passcode screen appeared	Choose <i>Set Up Later / Not Now</i> . Note the screen name in the manifest so BCH can adjust its configuration.
Signed in with an Apple Account by mistake	Stop. Erase the phone (see first row) and set it up again from Step 2. Tell BCH.

Per-phone bench checklist

Print one per phone (or per batch) and keep it with the device until it's packed.

Serial number

Technician

Date / Box #

- | | |
|---|--|
| ☐ Charged $\geq$ 50% | ☐ App Store → Automatic Downloads on |
| ☐ Serial label applied to phone back | ☐ App Store → Cellular App Downloads = Always Allow |
| ☐ English · United States | ☐ Rover opened — prompts accepted |
| ☐ Wi-Fi connected | ☐ Haiku opened — prompts accepted |
| ☐ Remote Management — enrolled | ☐ Label serial = Settings serial |
| ☐ Location Services enabled | ☐ BCH profile in VPN & Device Mgmt |
| ☐ Hub opened — prompts accepted | ☐ No damage |
| ☐ Hub location = Always + Precise | ☐ Case on |
| ☐ All apps installed, none waiting | ☐ Powered off |
| ☐ Locker opened — prompts accepted | ☐ Cable kept, retail box discarded |
| ☐ AutoFill → Locker on | ☐ Manifest row complete |
| ☐ Locker → Live Activities on | ☐ Packed — box # recorded |
| ☐ Cellular → Allow More Data on 5G | |